




The following installation details are provided as a supplement to Installation Instructions and Specification for the “PowerPlay Panel II” athletic floor system.




1. As shown above, prepare first panel by cutting to create a triangular section for placement in starting corner.
2. Assure that the channel pocket is aligned perpendicular to the flooring direction when panel is placed into position.
3. Provide 1-1/2" to 2" spacing between side edges of panel and walls.
4. As shown on the following page, use remaining ends from first cut panel to start 2nd row by rotating sections into position.
5. Allow 1/4" spacing between side edges and end edges of adjacent panels, and provide 1-1/2" to 2" spacing between panel edges and walls.
6. Attach panels to concrete substrate by installing steel channel section in each channel pocket and secure with one anchor pin. Provide equal spacing between channel ends and pocket end edges.




7. Cut panel corners as shown below to create triangular sections for placement in 3rd subfloor panel row.
8. Rotate sections and set into place with 1/4" spacing between ends of adjacent panels and maintain 1-1/2" to 2" spacing between panels and wall.




9. As shown below, use sections remaining from previous cut panels for placement in 4th row.



10. Cut panels as shown below for placement in 5th row.




11. As shown below, use sections remaining from previous cut panels for placement in 6th row.



12. As shown on the following page, cut panels for placement in 7th row. Thereby repeating the pattern when installing each row as was used for 3rd row.

13. Continue to provide 1-1/2" to 2" spacing between panels and walls, and between panels and all vertical obstructions. Allow 1/4" spacing between side and end joints of adjacent panel edges.

14. Attach panels to concrete substrate by installing steel channel section in each channel pocket and secure with one anchor pin. Provide equal spacing between channel ends and pocket end edges.



15. Trimmed sections that allow a minimum 16" offset of end joints in adjacent rows can be acceptably used to reduce waste.
16. Provide solid blocking below subfloor panels in closed stacked bleacher locations, below portable goals, and at doorways.
17. **IMPORTANT:** This installation guide is not a substitute for all other "PowerPlay Panel II" installation and specification instructions.